

Installation of Post extensions on wooden posts.

Tools Required.

Wrench for lag bolts, 1/4" drill for pilot holes, Screwdriver, Hammer if using staples into trees.



Screw the plastic clip onto the post near the top.

Holding the cat hoop horizontal slip it into the double clip then twist it through 90 degrees to secure.



Installation of Post extensions on wooden posts.



Drill a pilot hole 6 inches lower down.

Using a wrench fix the post extension to the post/tree with the lag bolt and large washer. Check that all post extensions are the same height , adjust as required.

Installation of the mesh

Roll out the mesh and attach the top of the fence material (straight edge) to the tip of each post extension with a fence tie.

The mesh goes on the outside of the fence.

At each major bend in the fence cut the material and restart, leaving plenty of material to overlap.

Always run the fence material past the point where you need to cut it to make sure you have sufficient material to overlap and attach to the posts and post extensions.